


You can disable or limit these by choosing between No Animations, Some Animations or All Animations from the Animation settings in Sound and Display (or Display in Froyo and newer versions).

iOS Leave some space

Never fill up your iPhone completely. Make sure to leave at least 500MB of free disk. This way your existing apps would be able to load and save documents, and get updates if necessary. Also, filling up your iPhone or iPod Touch to the brim with media files will result in a very slow running device.

Multitasking and viewing open applications

The primary new feature in iOS 4 is the ability to multitask. Unlike previous versions of iOS, you can now use multiple applications together.




An iPhone warning over disk space


You can also listen to music on Pandora, while checking your email or browsing the internet. To view all running applications and swiftly switch between different apps that are already open, double-tap on your iPhone's Home Button. Select the app of your choice and control it while the other apps are running in the background.

iPod Controls

In the previous versions of iOS before iOS 4.0, double-tapping on the iPhone or iPod Touch Home Button would give you access to the iPod controls, but now with the introduction of the multitasking feature, you will have to reach the iPod controls in a different way. Simply double-tap the home button and while the multitasking shelf shows up, slide to the left of the screen and then your



Tap on the iPod icon to access your music collection



You can listen to music even while sending an email

iPod controls come into view. You can add controls into this shelf like you do for Pandora.

Quitting applications

Multitasking is a brilliant feature in the latest version of iOS. Nevertheless, there are times when you want to close a program either because it's a hindrance and you don't want it to eat up your battery life by running in the background. In order to close an app, double tap the home button to access




You can easily quit applications


the multitasking drawer. Simply tap and hold on the app icon. The app should start jiggling with a red circle and a minus sign on the top left corner of the icon. Just tap on the red circle and it will shut down the app.

Lock the orientation of your screen

Because of the inbuilt accelerometer present on the iPhone, iPad as well as iPod, iOS automatically shifts orientation of the screen either from landscape to portrait and vice versa based on the movement of the device. At times, this would be undesirable. In order to lock the orientation of your screen, double-tap on the Home Button of your device for the multitask drawer to pop up. Simply swipe to the left menu and again to the left of the iPod controls. You'll see the orientation lock button. Tap on this to lock in portrait mode.



Portrait orientation locked




Searching on the iPhone is intuitive

Searching the web using Spotlight

Instead of opening Safari and navigating to a search engine, you can directly do it from mobile spotlight. Navigate to the search screen on your iPhone and type in what you are looking for. iOS will give you options to choose between Web or Wikipedia.

Folders

You'll begin using multiple home screens as the number of apps on your device keep growing by the day. By making use of folders, you can club multiple applications together into one icon and minimise the usage of your home screen space for better navigation. Tap and hold on an app till



You can move apps to folders