

Screw lock thwarts repair

Apple gives the feature of locking your iPhone 4 by tightening a screw provided on it, ultimately increasing the difficulty of repairing the device

"Dragontrail" protects smartphone

Asahi Glass Co. launched a strong, scratch resistant durable sheath cover to protect your gadgets from falls


Workshop

Illuminate your keyboard

It's hard to work on your keyboard in poor light conditions so we decided to reduce the strain you face while working late at night or under dim lights.

Kanchan Hira
kanchan.bira@thinkdigit.com

Photo: Jiten Gandhi



Collect all the components before you begin.



Unscrew the keyboard.



This is the inside part of the keyboard. You can see the PCB of the keyboard on the top right corner above.



Right most is the Scroll lock key LED. Unscrew the PCB and then de-solder the Scroll Lock key LED.



Remove the Scroll lock key LED from the PCB and connect two sets of wires at the points where the LED was connected.



Drill holes at the two top corners on the keyboard.



Screw back the PCB and then take out the wires from the PCB through the two holes you made on the keyboard.



Taking care of the polarity, solder the LEDs to both the sets of wires coming out from the hole then screw back the keyboard.



Connect the keyboard to the PC and then press the scroll lock key. You are now ready to face the dark with the power of your illuminated keyboard.