

1.6 Accessories For Your Digital Camera

Your digital camera may have bundled everything that you thought you may require, but if there's one thing we know is that there's always room for more. Most of these accessories are not really a must-buy for casual photographers, but if you're a prosumer, you may want to consider accessorising.

Batteries: As we mentioned earlier, digital cameras are highly battery intensive so it's highly recommended to keep at least one set of fully charged spare batteries on standby at all time. If your camera uses standard AA batteries, purchase two pairs of AA sized NiMH rechargeable batteries and use them instead of the standard disposable ones.

Memory Cards: A standard digital camera usually comes with a 16 or a 32 megabyte memory card which will definitely not suffice if you're going on a trip. Getting a bigger memory card will give you more room to experiment with multiple shots and even give you storage space for great videos. And since memory cards can be used as a portable storage media, you can even get a memory card reader to make it a portable drive when not in use in your camera. All in all, investing in more memory is never a bad idea.

Here's a chart that will help you select the memory card size to suit your needs:

Bags and Straps

Photos you can store in cards of various capacities							
Sensor	16MB	32MB	64MB	128MB	256MB	512MB	1GB
3 mp	13	26	53	106	213	426	853
4 mp	8	16	32	64	128	256	512
5 mp	6	12	25	51	102	204	409
6 mp	5	10	20	40	80	160	320

Most camera manufacturers generally provide a wrist strap and a little carrying pouch with the digital cameras. That's usually good enough for a casual user, but advanced users may want to invest in a good quality digital camera bag that comes with extra space