

3.You'll see a small icon sitting in the system tray once the drivers are properly installed and the hardware properly detected. Double-click the adapter card configuration icon in the system tray. This will launch the configuration utility.

4.Here, you don't have to do anything, as most of the settings, including SSID and the encryption key, are automatically picked up by the adapter card. Select the Ad Hoc mode if connecting to the other PC or laptop configured in Ad Hoc mode. Give an SSID different from the one assigned to the other wireless card.

5.Check the signal strength available at the place the wireless desktop or laptop is placed by double-clicking the utility in the taskbar.

Setting Up Ad-Hoc Mode

Ad-Mod or Peer-to-Peer mode as it is commonly known is very easy to set up. It has multiple advantages: you can quickly create a network between notebooks that are Wi-Fi enabled, and share small files during a meeting. It doesn't need an Access Point, as one of the notebooks can be turned into a soft Access Point, and the rest can connect to each other through it. Here is the stepwise explanation of how to turn a Wi-Fi enabled notebook into a soft AP, and to configure the rest to connect to it. We will use Windows to get the network up and running.

1.To set up the soft AP, click Start > Connect To > Wireless Network Connection. This will open up the Wireless Network Connection Dialog box. Here, click Properties; a new dialog box will open, from where we need to assign various settings.

2.In this dialog box, under the 'General' tab, scroll to 'Internet Protocol (TCP/IP)' and select it. Now click 'Properties', which will take you to the next dialog box where we assign the IP. Just assign the IP and click on the subnet mask once—it will appear automatically.