

Setup Utility 3.31a), the current values set under the 'Frequency / Voltage Control' submenu are as follows:

Spread Spectrum: Disabled (other available options: ± 0.25 , ± 0.5 , ± 0.75), CPU FSB

Clock: 280 MHz (100 to 280 - in steps of 1)

CPU Ratio: Auto ($\times 6.0$ to 12.0 - in steps of 0.5, 14.0, 15.0, 12.5 $\times$ 13.0)

CPU Vcore (V): Auto (1.625, 1.650, 1.675, 1.700, 1.725, 1.750)

DDR Voltage (V): Auto (2.6, 2.7, 2.8)

Termination Voltage (V): Auto (1.27, 1.29)

AGP Voltage (V): Auto (1.6, 1.7, 1.8)

I have also observed that when the CPU FSB Clock speed was set at the default value of 100 MHz, the processor was being recognised as an Athlon 1.25 GHz; and when the speed was set at 266, the processor was detected to be an Athlon 2000+, 1.67 GHz. Now the CPU FSB Clock speed is set at the maximum available option of 280, and the processor is recognised as a 2600+, running at 1.90 GHz. How do I get my processor to work at its designated speed of 2.083 GHz?

S. Sinha

A Wow! That's a complete list of specifications if we ever saw one. You certainly did your homework, and all the troubleshooting possible. Here's the dampener—there's nothing wrong with your processor. It's running at the correct speed. There are two versions of the AMD Athlon 2600+ available in the market. You have the latest version with 333 MHz FSB and 512 KB L2 cache; this runs at a clock speed of 1917 MHz or 1.9 GHz.

The older models clocked 2.13 GHz, but ran at 266 FSB with 256 KB of L2 cache. Check the AMD processor box, and you will see the clock speeds in the fine print near the bar-code. The Athlon XP 2800+ runs at 2.083 GHz.

Q I have an Intel 815 EGEW board, an 800 MHz Pentium III processor, 128 MB of RAM, and onboard Intel integrated graphics. I can't play games such as Quake III Arena and UT 2003;