

one manner. The processor has a small arrow pointing outwards, which is the way it has to be placed in the socket—the socket has a small blank space where the part of the processor with the arrow mark should be placed. Once you have put in the processor in the socket, it should fit snugly.



Finishing a socket type processor installation

Check the corners of the processor to see if you can feel if any part of the processor to be not on the same level as the rest of it. If there is, take out the processor and re-insert it properly. When the processor is properly inserted, you should be able to touch the surface and see that it is level on all sides. Now lower the lever until you feel or hear a click that indicates that the processor is locked in place.

4. Now, take the heat-sink/cooling fan combo that came with the new processor and place it gently over the processor. Attach the clips to the socket base on the motherboard.

Apply Thermal paste on the heat sink and the processor

