

in the side where it is to be held.

2. Keep the cooling fan on top of the CPU and gently press it down so that the screw on the top of the fan goes down the hole on the periphery of the CPU



Finally lower the lever to lock processor in place

This completes the installation of the CPU on the motherboard.