

2. Insert the floppy disk that contains the extracted BIOS files. If the BIOS update files contain a .bat file, then type the name of the .bat file at the command prompt and press [Enter], for



5 Set the boot order so that the computer boots from the floppy. Boot the computer using a Win98 boot disk, finally reaching the A: prompt.

example, A:/> xyz.bat [Enter] (In the above step, we have already saved the BIOS files on to the hard drive. This is an alternate method to flashing the BIOS using a floppy disk. You may also try this step if you want to.)

3. This should automatically start the BIOS flash process. You will be asked to provide the filename of the BIOS update file and once you do that, the process continues. If you are asked to make a backup of the existing BIOS, make the backup in a directory on the C: drive. At the end of the process, you will be provided with a result saying whether the BIOS update was successful or not. Finally, you will need to restart the computer.
4. If the BIOS update files do not contain a .bat file, you will have to perform the steps manually: at the command prompt, type in the name of the .exe file, such as 'A:\ flash879.exe' or 'A:\ awdf flash.exe'. Then press [Enter]. You will be then prompted for