

```

To get help, type HELP and press ENTER.

C:\>C:

C:\>dir

Volume in drive C has no label
Volume Serial Number is 10B-22B
Directory of C:\MSDOS

             (DIR)             06-02-85   1:24p
             (DIR)             06-02-85   1:24p

THUNDER.TXT                865
LDR/LDRNG.TXT              47,400  04-28-85   9:56p
HMSHSH1.BIC                5,328  01-28-82  10:14a
HMSHSH2.BIC                9,552  05-05-85   1:25p
CLDRSH1.BIN                324,288  06-02-85   1:30p
CLDRSH2.BIN                324,288  06-23-85   2:53p
STDRSH1.BIN                 8,112
STDRSH2.BIN                 8,112
                        2 files(s)      1,160,703 bytes
                        2 dir(s)        27,312.72 MB free

C:\MSDOS>dir /b /s /x

```

File listing of the BIOS update directory

- Before you restart the computer, remove the floppy disk from the drive. The newer BIOS version will be displayed at the bottom of the POST screen when the computer boots.

If you see a newer BIOS version, give yourself a pat on the back for having gotten a tricky job done!

For flashing the BIOS through proprietary motherboard BIOS software in Windows, there are some generic steps you need to follow. First, install the software that came with the motherboard. For instance, MSI motherboards have ‘MSI Live BIOS’, and Asus has ‘Live Update’, which basically mean the same thing. Software such as MSI Live BIOS is a part of a complete suite that includes live update for LAN and other system component drivers.

Once the software is installed, you will need to configure it for checking for updates on the motherboard manufacturer's Web site. The advantage with flashing the BIOS from Windows using the update software is that you don't have to depend on a floppy disk or worry about mistyping the filename. On the flip side though, you do need to have an Internet connection, and also pray that the power doesn't go off during the flashing process. Once