

2. Take the hard drive out of its case. Check the jumper settings on the back of the drive. If you are installing only a single IDE hard drive, or a SATA hard drive, you don't need to check the jumper settings. However, if you are installing two IDE hard drives, you will have to check for the jumper settings on the back of the drive.
3. Do not fiddle with the jumpers of the drive that you decide to make the master. Change the jumper settings of the drive that you decide to make the slave, according to the instructions on the back of the drive.
4. Insert the drive in the empty bay in the computer case. Make sure that you can see the screw holes on the sides of the hard drive on either side of the cabinet. Fit the screws that came with the hard drive into these holes and secure the drive.
5. Connect the IDE or SATA cable on the back of the drive and then attach the power cable. The IDE or SATA cable will only fit in one way, so you cannot damage the hard drive; however, take care that the connector pins on the back of the drive don't bend when you're plugging in the IDE cable.

Floppy Drives

The floppy drive is the only device that hasn't undergone any change from the time of the Pentium 1, and is probably the only thing you can cannibalise from your older system when you are upgrading to a new one. External storage options such as CD-ROM and DVD may have put the floppy drive in the back seat, but if you have a bad BIOS flash and want to revive your computer, or if you want to install Windows XP on a RAID-enabled motherboard, you will have to rely on that old, dusty floppy drive.

Upgrading the floppy drive doesn't make sense unless it is broken or if you are selling your older computer. A new floppy drive