

and the speaker, while the keys are placed on the lower half. The phone is shut when not in use, hiding the screen and buttons. Most clamshell phones also boast of dual LCD screens: apart from the main screen on the inside, there is also a secondary, smaller screen on the outside that displays information such as the time, battery status, caller information etc. Depending upon the model, the two screens can have different screen resolutions and colour capabilities.

Most phone models using this form factor have also an 'Active flip' feature, which means that calls can be answered and ended by opening and closing the phone. In most cases, the size of a clamshell phone is quite compact when closed as compared to candy bar phones.



A Clamshell Phone

Flip

A flip phone is a cross between the bar and clamshell. Here, most components including the screen and the keys are placed on the bottom half of the phone. The top half is usually a plastic flap that folds on top. Again, depending upon the phone model, the top half may contain a speaker and even a transparent window that enables the user to see a portion of the screen when the phone is closed. The visible part of the screen displays the time and caller ID information. Most flip phones also have the active flip feature.