

tem performance a little: go to the Control Panel and open the System dialog. Under the Advanced tab, click on the Settings button under Performance. Under the Advanced tab here, adjust for best performance of Background Applications. This can cause quite an improvement in sound performance. You should also close all unnecessary programs that may hog memory. If you're still insistent on running many programs at the same time, including sound applications, upgrade!

### Codec Woes

If you're experiencing bad sound quality from only specific file types, it's more likely that the codec is either damaged or just badly written. If it's the former, all you need to do is reinstall the codec, but if it's the latter, you need to wait for a patched version that fixes the error. In case of any problems with specific filetypes, we recommend first installing the K-Lite Mega Codec Pack (which we put on every *Digit* CD) before going any further.

### Software Woes

If it's a particular software or game that outputs distorted sound, it might be a problem with the software itself. Check with the developer if there is adequate support for your sound hardware, and if a patch is available for it.

## 4.3 Bringing it Home

---

What could go wrong during a recording or CD-Ripping session?

### Sound Card Woes

If you have an external sound card, make sure it's selected as the Default Recording device. Right-click on the Volume icon in the System Tray, select "Adjust Audio Properties", and look under the Audio Tab. Under Sound recording, select your sound card as the default device.

### Microphone Woes

A common hassle with microphones is the horrifying sound your speakers make the moment you connect them. This is called *feed-*