

cated. Hence, check the settings for the printer. Go to **Start > Settings > Printers and Faxes**, right-click on the printer and go to **Properties**. There you will be able to see this option. The setting here should match the rated setting of the printer. If this is not a problem, then it may be that the printer



Laser Printer

spools all tasks to the hard disk before printing any task; over a period of time, your hard disk may have become clogged with all this data, leaving you with no space to spool tasks. This can be fixed by clearing some space from your hard drive.

There's another, remote possibility: the memory chips might have become loose or perhaps damaged. In that case, you'll need to contact a technician.

► **Problem:** Your printer prints garbled text.

Cause: It could be a corrupt driver, or the problem could be with the print head—worn-out pins or badly-rotating pin cushion rollers.

Solution: If reinstalling the drivers doesn't help, you'll need to call in a technician.

► **Problem:** When you try to print, you get a message saying "Error writing to LPT1".

Cause: There are multiple possibilities.

Solution: There are quite a few ways to fix this error. First, make sure the printer is online and that there is sufficient paper in the tray(s). Then, clear the printer's memory by turning off the printer, and check whether the printer cable is properly connected. If you still get the error, remove the printer drivers by going to **Add/Remove Programs**, and reinstall them. If you still can't print, then check the parallel port settings by right-clicking **My**