

6.4 gigabytes of memory! As a rule of thumb, a PC should have at least as much RAM as the size that will be occupied by the image to be scanned, and at least double the free disk space on the hard disk. A higher amount of free space will improve the scanner's (and the computer's) performance.



Multi Function Device Scanner

Note: CMYK scans are 25 per cent larger than RGB scans, while greyscale scans are a third of the size of RGB scans.

► **Problem:** The colours in your scanned photographs don't appear the same as the original.

Cause: You're probably scanning at a low colour bit depth.

Solution: Try increasing the colour depth of the scanner in the manual scan options. You should also check if your display adapter is set to display the highest colour bit depth from the Display Properties in the Control Panel.

► **Problem:** While some applications are able to scan from your scanner, there are some that are unable to locate a scanner.

Cause: The incorrect scan source has been selected.

Solution: In order to use a scanner with an application, you need to choose the TWAIN source corresponding to the scanner you're using. You will be able to select the TWAIN source in the application, most likely under the File menu.

10.2.1 How to get the best out of your scanner

Selecting the scanning area: Always preview the document and select just the area to be scanned, instead of scanning the entire document. This will reduce the scanning time as well as the file size, especially when scanning at high resolutions.