

Web site at <http://support.microsoft.com/?kbid=885222> which addresses this issue.

- **Problem:** Your external FireWire DVD-RW drive is not detected by XP.

Cause: This is a bug in Windows XP.



Solution: Microsoft suggests you install at least Service Pack 1. This will solve, in most cases, problems faced while hot-plugging FireWire devices such as DV Cams, DVD-RW drives, etc. The other possible solution is to open the Device Manager and if you see an exclamation mark beside the

FireWire controller, uninstall the controller and restart the computer.

10.3 Glossary

BIOS: Basic Input Output System, which handles the communication between the computer and its peripherals. Often burned onto read-only memory (ROM) chips or rewritable Flash (EEPROM) memory chips found on motherboards and expansion cards, such as video cards and SCSI and ATA/IDE host adapters.

Bit depth: This is the number of bits used to describe the colour of each pixel on a computer display. For example, a bit depth of two (2 to the power 2) means the monitor can display only black and white pixels; a bit depth of four (2 to the power 4) means the monitor can display 16 different colours; a bit depth of eight (2 to the power 8) allows for 256 colours, and so on.

CMOS (Complementary Metal-Oxide Semiconductor): A type of chip design that requires little power to operate. In PCs, a battery-powered CMOS memory and clock chip is used to store and maintain the clock setting and system configuration information. The PC BIOS is built on such a chip.