

Once you've identified the device(s) with problems, double-click on the device to bring up the property page for the device. The property page or sheet has a General tab that shows the details of the device, and its current status (enabled or disabled). Depending on the type of device, there may be additional tabs such as Resources, Driver and Settings.

1.5.7 Device Manager Error Codes

Additionally, a problem code explaining the problem is displayed for the device. The next step is to understand what each of these error codes mean and apply the recommended resolution. The list of problem codes and the recommended resolution are as follows:

Code 1

Code Meaning: The device is not configured correctly.

Recommended Resolution: The software drivers for the device have been incorrectly installed or incorrectly configured. Select the Driver tab and click the Update Driver button. This will launch an update Wizard. Follow the instructions and locate the correct driver for the device to install it.

Additionally, you could try removing the device from Device Manager and reinstalling it using the Add Hardware Wizard.

Verify from the hardware documentation/manufacture's Web site that the device will work with your OS.

Code 2

Code Meaning: (Not applicable to Windows XP) Depending on the type of device, this could indicate either a problem with the BIOS or a problem with loading the device driver.

Recommended Resolution: Check with the BIOS manufacturer for an updated BIOS. See the *BIOS* section of this guide on how to update the BIOS.

OR