

AND/OR

Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

Code 9

Code Meaning: (Not applicable to Windows XP) The BIOS is reporting the resources for this device incorrectly and the Windows Registry is invalid.

Recommended Resolution: Run the Update Driver Wizard and reinstall the driver or get an updated driver and the correct Registry entries from the manufacturer.

AND/OR

Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

OR (as a last resort)

Reinstall Windows.

Code 10

Code Meaning: The hardware will report the reason for failure that Windows should display. If the hardware doesn't report the reason for failure, Windows will say that the device is not present, not working correctly or does not have all the required drivers installed.

Recommended Resolution: If the failure message is present, use that to troubleshoot the problem by referring to the documentation or manufacturer's Web site.

AND/OR

Run the Update Driver Wizard and reinstall the driver or get an updated driver from the manufacturer.

AND/OR

Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

Code 11

Code Meaning: (Not applicable to Windows XP) Windows stopped responding when it tried to start the device, and hence will never try to start this device again.