

Code 28

Code Meaning: (Not applicable to Windows XP) The driver for the device was not installed correctly.

Recommended Resolution: Use the Update Driver Wizard to reinstall the driver.

AND/OR

Remove the device from Device Manager. Reinstall it using the Add Hardware Wizard.

Code 29

Code Meaning: The device has been disabled in the BIOS, or the device will not work with the version of Windows you are using.

Recommended Resolution: Enable the device in the BIOS. Refer to the motherboard documentation for details and see the BIOS section of this guide for further information.

Code 30

Code Meaning: (Not applicable to Windows XP) An IRQ that cannot be shared is being used by this device and another device driver.

Recommended Resolution: View the resource conflict in the resources tab, if available. Refer to the manufacturer's documentation for either device and change the IRQ allocation manually. You can do this by clearing the "Automatic Settings" checkbox and clicking the "Change Settings" button.

Code 31

Code Meaning: To function properly, the device depends on another device which is not functioning properly. Most likely the other device will also have a error code.

Recommended Resolution: Troubleshoot the dependant device to enable this device. If they still don't work, remove them from Device Manager and reinstall them using the Add Hardware Wizard.

Code 32

Code Meaning: (a) The installation disk/CD-ROM or network location was not accessible to install the device drivers.

(b) A driver or service for the device has been disabled.