

Stop Code: STOP 0x0000000A

IRQL_NOT_LESS_EQUAL

Code Meaning : Faulty device drivers, or services from backup utilities or virus scanners

Recommended Resolution: Remove, disable or stop the offending drivers, backup utilities or anti-virus programs. Get updated software from the manufacturer.

Stop Code: STOP 0x0000001E

KMODE_EXCEPTION_NOT_HANDLED

Code Meaning: Some driver files may be causing a problem.

Recommended Resolution: Remove, disable or update the driver-file listed in the error message. Verify if new hardware installation is correct.

Stop Code: STOP 0x00000024

NTFS_FILE_SYSTEM

Code Meaning: Usually caused by disk corruption in the NTFS file system or third-party disk defragmenters.

Recommended Resolution: Use hard disk diagnostic software to verify that the hard disk is working. Remember to always Use Microsoft-certified disk defragmenters.

Stop Code: STOP 0x0000002E

DATA_BUS_ERROR

Code Meaning: Caused by a parity error in the system memory. Almost always caused by hardware problems—a configuration issue, defective hardware, or incompatible hardware.

Recommended Resolution: If physical RAM was recently added to the system, remove it and see if the error still occurs. If the error persists, try disabling memory caching in the BIOS. Else remove, repair or reinstall the defective hardware.

Stop Code: STOP 0x00000050

PAGE_FAULT_IN_NONPAGED_AREA

Code Meaning : Caused when requested data is not found in memory; the system checks the page file, but the missing data is