

identified as unable to be written to the page file

Recommended Resolution: Remove any newly-added hardware or run diagnostic software supplied by the manufacturer to check if the component has failed. Install updated device drivers or roll back to a previous driver.

Stop Code: STOP 0x0000007B

INACCESSIBLE_BOOT_DEVICE

Code Meaning: Caused when Windows loses access to the system partition during the Startup process. This can be caused by: an incorrect driver for a SCSI, RAID, or UDMA IDE controller; incorrect ARC path in the Boot.ini; or a failed boot device.

Recommended Resolution: Verify that the disk storage device is installed correctly and working. Reinstall or update the device driver. Verify that the BIOS setting for the device is correct. Verify the integrity of the hard disk.

Stop Code: STOP 0x0000007F

UNEXPECTED_KERNEL_MODE_TRAP

Code Meaning: Caused when the CPU generates an error that the kernel does not catch. Usually hardware related—especially RAM. Can also be caused by CPU overclocking, or defective components on the motherboard.

Recommended Resolution:

1. Run the memory diagnostic to test RAM.
2. Restore overclocked settings to previous values.
3. Repair/replace the motherboard.
4. Disable sync negotiation in SCSI BIOS; check SCSI termination.

Stop Code: STOP 0x000000D1

DRIVER_IRQL_NOT_LESS_OR_EQUAL

Code Meaning: Occurs when the system attempts to access pageable memory at a process IRQL that is too high

Recommended Resolution: Very similar to STOP 0xA. Remove, disable or stop the offending drivers, backup utilities or anti-virus programs. Get updated software from the manufacturer.