

fer to display an error message on the screen. Beep codes are used only if the BIOS can't access the display subsystem.

One long beep: Memory problem

Problem: A problem with the memory or motherboard

Solution: Troubleshoot the memory and the motherboard

One long and two short beeps: Video error

Problem: The BIOS is not able to access the video sub-system

Solution: Troubleshoot the video card, and if the problem persists, go on to the motherboard.

One long and three short beeps: Video error

Problem: The BIOS is not able to access the video sub-system

Solution: Troubleshoot the video card, and if the problem persists, go on to the motherboard.

Continuous beeps: Video / memory problem

Problem: There is a problem with the RAM, display card or motherboard.

Solution: Troubleshoot the RAM first, followed by the display card and then the motherboard.

Other beeps: Check the motherboard manual

Problem: Check the motherboard manual or the vendor's Web site for more information. Treat it as a motherboard problem.

Solution: Check the motherboard manual. Troubleshoot the motherboard.

2.3 General BIOS Problems

► **Problem:** The BIOS fails to detect the hard disk(s), CD-ROM, floppy drive, etc.

Cause: All of a sudden, hard drives and floppies disappear from the list of devices, or you cannot boot because the BIOS declares that you have no hard drive!