

in the main interface. WMP usually detects the device and displays all the songs currently on the player. To transfer files to your device, click 'Edit Playlist' in the Sync interface menu. It will show you a list of all the media files on your computer sorted by Artist. You can select the sorting parameter in the drop down menu. Once you have selected the files you want to transfer click 'Start Sync'.



WMP has the option of Automatic updates as well

Like iTunes, WMP does not allow you to transfer files from the device to your PC. WMP also has the option of automatic updates to your device. Simply click 'Set Up Sync' in the Sync interface menu, and select the 'Automatic' option.

12.3.3 Musicmatch Jukebox

MJ also has a pretty nifty sync option with portable devices. Connect your device to your computer and select 'Portable Device' in the Copy menu of the main interface of MJ 10. It detects the device and displays all the tracks on it. You can add songs to the player by clicking 'Add Tracks' and selecting them from your Library. MJ has a lot of additional functionalities as well, apart from the regular Automatic Updates, etc. Click on the 'Tools' drop down and select 'Settings'. Here you can configure a variety of options including volume leveling and overwriting duplicate tracks on your device.



MJ offers additional options for devices