


Once you have your sound card, microphone and speakers in place, you will need to set them up for recording. If you're using the microphone, there's nothing more you need to do in terms of setting up. If you want to record from a cassette player or from a musical instrument, however, you will need to connect the audio output of the source to the line-in of the PC.

Next, see if you have the little speaker icon in the taskbar and double-click it. If

not, you will have to go to Control Panel > Sound and Audio Devices, and then check "Place volume icon in the taskbar". Click Apply and then OK, and you will see the speaker icon. If the option is greyed out, you will need to make sure your sound card drivers are installed, and that there are no devices with yellow exclamation marks (meaning wrongly configured hardware) in the Device Manager.

Once you double-click on the speaker icon, you will see the volume controls pop up. Now, click on Options > Properties, and select the Recording radio button. Under the "Show the following volume controls" head-



Check the appropriate box to display the Volume Control icon in the Taskbar



You can choose what settings you want to see in the Recording Control box