

do so normally. Then play back the sound to make sure it isn't too loud or too soft. If it is either too loud or too soft, you will have to go to the Recording Control—Start > Run, type in “sndvol32 -record” and press [Enter]. Here, increase or decrease the volume of the microphone as required.

Once you've set a satisfactory volume, you should be able to hear your voice clearly without any distortion or jarring. This means that your microphone is set optimally. If you don't change any volume control settings, this should be a permanent tweak. You're now set to record using the microphone. In order to record from the line-in input on your card, you will have to do all the same tasks you did to set up your microphone (except for sound-proofing your room).




You can use the “sndvol32 -record” command to get directly to Recording Control

6.1.3 Recording Using Audacity

Start up Audacity, and the first thing you should do is head to Edit > Preferences, or press [Ctrl] + [P], and under the Audio I/O tab, make sure your sound card is selected as the source for both Playback and Recording. Also make sure that the number of channels is set to “2 (Stereo)”, or else everything will record in mono!

Now make sure you've connected the device you are recording from to the correct input jack (microphone or line-in), and also that the same is



First set Audacity to record in stereo from the Preferences