

and follow the on-screen instructions. These may differ based on your phone model, but you can take the steps mentioned below as a rough guideline to updating your phone.

1. Make sure your phone is fully charged, Nokia PC Suite is installed, and for safety, keep your phone charger on and connected to the phone for the duration of the update. Your PC configuration should be at least a 1 GHz CPU with 512 MB of RAM, preferably running Windows XP and with a fast and reliable connection to the Internet (256 Kbps, always-on is fine).
2. Back up everything! After you flash your phone software, you might find that all personal data has been erased, similar to using the restore factory defaults setting in most phones today. Use the Nokia PC Suite to backup *everything*— all the data in your phone as well as memory card, such as contacts, messages, call registers, ringtones, themes, music, videos, etc.
3. Download the Nokia Software Updater from the site we mentioned above, choose English as the language, and save it to disk.
4. Before you run the utility, make sure you have an hour to spare; the process, once started, cannot be stopped.
5. Run the Software Updater; it will prompt you to back up your phone data. If you haven't, do so. Click Start after you have used PC Suite to back up everything.
6. Connect your phone via USB to the PC; from the update modes shown, select Nokia PC Suite. Click Next.
7. The Software Updater will connect to the Net and search for the latest firmware version for your phone. When it finds the update, it will again warn you about backing up data, and ask for your acknowledgement by asking you to tick a checkbox. Click Update.
8. The firmware will be downloaded, during which you are allowed to Cancel the download. After the download is finished, the Cancel option is greyed out and you have no choice but to wait while the phone is updated.