

6.10 Connecting And Using Peripherals

Most USB and FireWire cameras, camcorders, and storage devices used on a PC can also be used on a Mac. To check for compatibility, go to Apple's peripheral compatibility site at www.apple.com/macosx/upgrade/devices.html.

Mac OS X has built-in support for USB mice and keyboards. You can use a two-button mouse and a mouse with a scroll wheel. Check the mouse manufacturer's Web site for Mac OS X software to enable other features, or go to the Apple Drivers site at www.apple.com/downloads/macosx/drivers.

Mac OS X supports many USB and FireWire digital cameras and most FireWire camcorders. iPhoto and iMovie open automatically when you plug in a camera or camcorder. Click Import to import photos or movie clips.

Mac OS X supports most USB and FireWire storage devices. When an external hard disk, CD burner, Zip drive, or other storage device is plugged in, an icon appears on the desktop. The manual that comes with Macs also provides information about connecting and using USB and FireWire devices.

Most Macs work with any VGA-compliant display or projector. Some Macs also work with DVI displays and displays that use the Apple Display Connector (ADC). The documentation that comes with Macs can be read for more information.

6.11 More About Macs

Want to find out more about using a Mac or solve any problems? The Apple Web site provides an easy and convenient place to look.

Tips and Support

For tips and support information about Macs, visit the Apple