

print of thicker media, besides increasing the chances of paper jams. Some printers print on the reverse side of the page, with reference to how the paper is placed in the tray, indicating a U-shaped paper path.

3.2.11 PictBridge

A protocol that allows digital cameras and photo printers to directly interact without the need to connect through a PC.

3.2.12 PostScript

A device-independent printing language. Documents sent for printing from any system are first converted into Postscript.

3.2.13 PPM

This refers to the maximum pages that can be printed by the printer in a unit time, expressed as pages per minute (ppm). Printing speed varies with the content, coverage, and colour qualities. Printing pictures takes more time than text, printing closely-typed text takes more time than printing double spaced text, and printing a colour image takes more time than printing the same image in monochrome.

3.2.14 Print Job

The pages sent to the printer at one time together constitute a job.

3.2.15 Print Media

The surface on which a printout is taken. Most printers allow printing on normal paper sheets as well as thicker envelope covers. Photo printing requires the much thicker photo paper which is specially treated to prevent ink blot. The paper path influences the print media that is supported by the printer.

3.2.16 Print Quality

Printers support printing at different quality settings, usually termed Draft, Normal, and Best. The quality setting influences the print speed. In draft mode, the print resolution is lower, as is the amount of ink or toner used. Best mode gives the highest possible