

Using the VCB for Rectangles

Soon as you begin drawing a rectangle using the Rectangle tool, you'll see the dimensions of the rectangle dynamically being displayed in the Value Control Box (the label "Dimensions" will also be visible just outside the VCB).

- You can draw an entire rectangle and fill in the length and breadth values as per your requirement (before you begin any other operation). Simply typing two numerals separated by a comma—and then pressing [Enter]—will do this for you.
- Alternatively, you can simply set the first corner of your rectangle by clicking once and then putting the values of length and breadth in the VCB.
- Uniquely, you could even type in a single dimension at a time (just the length or just the breadth). This will change only the dimension you have mentioned and the other two sides of the rectangle will remain of the same length as before. Thus, entering a value followed by a comma in the VCB, (for example, 33",) then the new value will only be applied to the first dimension and the length will change to 33 inches. Similarly, typing in the value after a comma (for example, , 33") will change only the second dimension.
- Negative values will change the direction in which your rectangle is being drawn. Any further values will now be understood to now refer to this new direction.

Using the VCB for Circles

Every time you draw a circle, the VCB shows you the value of the radius from the centre point. You can specify the exact length of the radius by typing the numeral in the VCB while drawing a circle (or immediately after you've drawn one). For your convenience, the "Radius" label will appear outside the VCB on the status bar below. The process is easy:

- Choose the circle tool. The cursor will change to a pencil with a floating circle.
- Click on a point in the drawing area to choose the centre point of the circle.
- Type the value of the radius of the circle. Press [Enter] .
- Simply typing in the value is enough. However, you can specify the