

Whenever it says limited connectivity, I restarted the modem several times. It still has the same problem. I have seen that the green LAN LED always glows. The red LED, which is normally indicative of being busy, but it sometimes blinks or sometimes periodically like every after 3 seconds.

I have installed all the LAN drivers. In my laptop, the Intel Pro/100 VE Network LAN connection is there. I don't know how to check whether my LAN has gone or what? I have tried all the possibilities, but it doesn't connect at all. I have a 2 Mbps connection. My WiFi works just great. However, LAN has the same problem.

Other than driver what would be the problem in my LAN? Can anyone please solve my problem? I will be very thankful to them.

Nkparsana

A Call your ISP and ask them to check the connection.

aswin1

Go to IP v4 properties in network setting (LAN) and assign IP address as 192.168.1.2 and the netmask as 255.255.255.0. Reboot the modem and PC. Then go to ADSL modem properties by opening 192.168.1.1 (or what ever your router's IP) on your browser and see if DHCP is enabled. This will help.

nish_higher

150 feet, can I create a LAN?

Q My house and my friend's house are 150 feet apart. We want to make a LAN. Is this possible with an RJ45 and CAT5? If yes, tell me what we need? If not possible, then tell me any other way to make it. If possible, tell me approximate expenses.

Tech.Masti

A Nothing extra is needed. This is a small distance only. Just connect directly. Don't forget to get the PC-to-PC Ethernet cable (cross-over cable if connecting PC-to-PC) or else get the normal cable if you are using a router to connect the PCs.

The network will be good when you have a router that becomes hassle-free. Else, you have to deal with small problems in directly connecting two PCs over LAN

DigitalDude