

either my system hangs or the CPU usage shoots up to 100 per cent (without indicating any device connected). At times, I thought it could be a virus present in those devices, but those same devices work absolutely fine on other systems. But, when I connect some other devices such as my mobile or my MP3, the device gets detected and runs fine. I have already formatted and reformatted my system several times and reinstalled the drivers, but the problem persists.

So, I request you guys to please help me out of this situation. Just because of this problem, I still have to rely upon my CD writer to carry data as I am not able to buy a pen drive for myself. Please help. My motherboard is Gigabyte 845i and I use a Pentium 4 2.4 GHz processor).

Piyush Gurung, Dehradun, Uttarakhand


A Be sure to install the latest drivers from the Internet for your motherboard. An antivirus on Windows could also be locking up the USB drive trying to scan it. If you can get your hands on a Linux LiveCD, boot into it and try connecting your flash drive. See if the drive is accessible. Try attaching the drive to some of the other USB ports or detach all USB devices and use the flash drive.

Hardisk Problem

Q My problem is that my hard disk (WD-250GB) is detected as a removable drive. Please help. My Configuration is AMD (Athlon) 5200+ Processor and ASUS VM Board 1GB RAM.

Avin Tokade

A The detachable drive is to do with NVIDIA drivers and Windows XP. Try installing the latest motherboard drivers. There is a quick fix if the problem isn't solved. Start your registry editor by clicking on Start > Run > regedit. Browse to HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\



A small registry change can get rid of the removable disk icon for your internal drive