

A Firstly, see if your computer has a graphics card (a simple TV Tuner / capture card will suffice). Secondly, see if the handycam has an S-Video port. If yes, then you need to buy an S-Video cable. Connect the cable to the graphics card slot.

Run Windows Movie Maker v2.0 and capture the video from the handycam. You should have sufficient space (20+ GB) in the HDD partition that you would store the captured file. Save the captured file (MPEG4 format) in the HDD. Run Nero and convert the captured file to VCD / SVCD format and write it on a blank CD.

Addendum: Prior to start capturing, you should connect an audio cable from handycam to the sound card of your computer to capture the audio.

avik_chat


Urgent: System Crash!

Q I am getting the following message when I switch ON my PC:
Reboot and select proper boot device or insert boot media in selected boot device. In addition, I'm unable to open C: from the recovery console.

I'm getting the following message: Fixboot cannot find system drive, or the drive specified is not valid.

Ron

A I think the HDD has gone kaput. First check whether the HDD is properly detected by the system BIOS. If it is, then it can be a case of partition loss only. Otherwise, you're out of luck. Prepare to purchase a new one. If it's partition loss, try various tools that are available both for free and paid ones. I once lost my partitions while installing Linux, I used the Ultimate Boot CD. It contains a utility called testtool, which is a text UI-based one, but works very nicely. And yes, do check the data and power cables of the HDD also.



The Ultimate Boot CD has utilities for recovering from system crashes and problems.

Krazy_About_Technology