

Night:

A slow shutter and a small aperture are used to capture photos of buildings or other lighted facades at night. Do not use this mode to capture photos of people at night, for which the night portrait mode is used. This mode does not use flash, and the camera will have to be stable to produce a clear, crisp image. In fact, we recommend you to use a tripod to avoid blurred images. Use this mode to produce abstract images or trails by moving the camera around with the shutter open. Some cameras employ algorithms that reduce blurring in this mode.

Night Landscape:

A large aperture, high ISO and a slow shutter speed makes this combination notorious for producing shakes. This mode is used for capturing landscapes at night, without the use of flash. This means that the camera will have to be very stable.

Night Portrait:

This is a tricky mode to operate in. Flash is used to illuminate the subject in the foreground, while a slow shutter speed is used to bring out background details. The camera will have to be very stable to prevent shakes. A small depth of field is used, so the background will be out of focus. Be careful not to stand too close to the subject, as this will overexpose their face with the flash.

Party:

The party mode uses a high ISO, with a large aperture and a fast shutter speed to capture images in low light conditions. Flash may or may not be used in this mode. Some cameras also use image stabilization and blur reduction, but the low light conditions are not conducive to clear and crisp images.

Picture stabilization:

A fast shutter speed is used to reduce blurring. Should be used inside a moving vehicle, or on any kind of moving platform. Algorithms for reducing the effect of camera shakes are applied in this mode.