

Camera Care

Cameras need to be handled with care and require periodic maintenance to keep them in good condition. Some cameras need extra care while handling. DSLRs should be serviced regularly. Point-and-shoot cameras, on the other hand, are a little simpler and have fewer things that can go wrong if not taken care of. Tasks as simple as wearing a neckstrap with the camera attached can prevent accidents. In the long run however, there are many other things that can be done to extend the life of your camera.

11.1 Lens cleaning and maintenance

The lens is one of the most important parts of the camera that requires the most cleaning. It is after all, the part that is directly exposed to the open when in use and also is directly linked to the quality of the image. Any dirt or marks on it will end up in some way or the other in the images you take. One of the ways you'll know is if your photos have unexplain-



A lens cleaning brush can help clear any dust on the lens

able blurry spots in all the photos.

As much as possible, the lens should not be touched. The lens cover should be on the lens at all times. If you have multiple lenses, then make sure the ones not in use are covered on both ends.



Lens cleaning kits for cameras are available