

Use the up and down keys to flip through the frequencies until you reach the frequency of your preferred station. Some older radios without digital displays (radios that have a knob and a dial with moving arrow to indicate the frequency) usually have two knobs for tuning. One is labelled rough and the other fine. Adjust the knob labelled rough to approximately the frequency you desire (until you start hearing something) and then use the knob labelled fine to tune it to a much clearer signal. The FM radio tuning process is simple.

Some newer radios come with an option known as scan. This button automatically searches for stations. Keep pressing the button repeatedly until your desired station is found.

Tuning your TV involves slightly higher levels of complexity. However, most TVs and set top boxes today come with a built-in auto tune option. All you have to do is turn this on and it will find all the channels within the specified spectrum. Digital satellite TVs and set top boxes also often require you to select the satellite to which you are tuning. Find the specifications from your channel and tune for it. The specifications for a typical satellite TV channel include:

- Frequency
- Satellite
- Polarisation (Horizontal/Vertical): this feature decides what plane the oscillating electric fields of the carrier wave are confined to (Chapter 1).
- Symbol Rate: this is roughly a specification of the bandwidth of the station, as multiple stations might be broadcasted at the same frequency.
- FEC (Forward Error Correction): a technique wherein each piece of data is repeated multiple times, to create more reliability due to redundancy.

All these specifications will be available for the channel you are searching for at its website or any other promotion materials. All you need to do is enter these specifications, and click for search. The set top box/TV should automatically find you the channel you require.