

router. After a minute, the internet, WAN, or WLAN light on your wireless router should light up, indicating that it has successfully connected to your modem.

Configure your wireless router


Using the network cable that came with your wireless router, you should temporarily connect your computer to one of the open network ports on your wireless router (any port that isn't labelled internet, WAN, or WLAN). If you need to, turn your computer on. It should automatically connect to your router.

Next, open Internet Explorer and type in the address to configure your router. The address and other similar details should be given in the user's manual of the router.


You might be prompted for a password. The address and password you use will vary depending on what type of router you have, so refer to the instructions included with your router.

Internet Explorer will show your router's configuration page. Most of the default settings should be fine, but you should configure three things:

- Your wireless network name, known as the SSID. This name identifies your network. You should choose something unique that none of your neighbours will be using.
- Wireless



Entering the username and password



Naming the network