


If that is the case, check if the above instructions have been followed, and if all the


connections between the router and modem are tight.

Follow these steps to connect your computer to your wireless network:


- Right-click the wireless network icon in the lower-right corner of your screen, and then click View Available Wireless Networks.



The pop-up alerts you of your connection status



View available networks



Connection to a Wi-Fi network is a matter of clicks