



Made of virtually indestructible polycarbonate armour, the Logitech PlayGear Street Case protects your PSP from bumps and crashes, as well as allots slots for storing up to three UMD discs and four Memory Stick Dup cards at a time

with throwing in cord management, for those who like to listen to some tunes on their PSP.

It comes with an adjustable strap letting you wear it comfortably three different ways – carried as a shoulder bag worn across your chest; messenger style; and attached to a backpack.

The PlayGear Street Case isn't easily available in the retail markets in India, so your best bet is to look online or go for a walk through grey markets.

3.1.3 INTERFACE

XrossMediaBar

Before the Xross Media Bar (pronounced 'Cross Media Bar') ever came to the PlayStation 3, it was cavorting around on the PSP.

On the PlayStation Portable, once a category is selected, its options appear below the icon, selectable by pressing right on the directional pad. Going back is possible by pressing the left directional button or the Circle or X button. Some items have an option menu that can be displayed by pressing the Triangle button.

The XMB is capable of limited multitasking. This is accessed by pushing the 'Home' button on the 1000 and 2000 PSP version and the "PS" button on the 3000 PSP, while listening to music, looking at photos, etc.

This feature can be used to watch a video, look at a certain photo, listen to music, and look at the current web page, all while browsing the XMB. However, what is in the background will be cancelled if any item is accessed on the XMB.