

Function:	Output an entire byte to a port. The direction register is changed in accordance with the last specified <code>#USE *_IO</code> directive.
Availability:	All devices, however not all devices have all ports (A-E)
Requires:	Nothing.
Examples:	<pre>OUTPUT_B(0xf0); // B7,B6,B5,B4 have 1 as output // B3,B2,B1,B0 have 0 as output</pre>

SET_TRIS_A()

Syntax:	<pre>set_tris_a (value) set_tris_b (value) set_tris_c (value) set_tris_d (value) set_tris_e (value) set_tris_f (value) set_tris_g (value) set_tris_h (value) set_tris_j (value) set_tris_k (value)</pre>
Parameters:	value is an 8 bit int with each bit representing a bit of the I/O port.
Returns:	undefined
Function:	These functions allow the I/O port direction (TRI-State) registers to be set. This must be used with <code>FAST_IO</code> and when I/O ports are accessed as memory such as when a <code>#BYTE</code> directive is used to access an I/O port. Using the default standard I/O the built in functions set the I/O direction automatically. Each bit in the value represents one pin. A 1 indicates the pin is input and a 0 indicates it is output.
Availability:	All devices (however not all devices have all I/O ports)
Requires:	Nothing.
Examples:	<pre>SET_TRIS_B(0x0F); // B7,B6,B5,B4 are outputs // B3,B2,B1,B0 are inputs</pre>