

the ground when the motor is placed on ground in such a way that its curved surface touches the ground. After removing the highlighted portion of the box, the hole will be created. Make a similar hole on the other side also.



Now, keep the motors in place and insert their axle in the holes. Secure the motors in place with the help of some insulation tape.

Now, as the motors are secured in place, put the wheels on axle and fasten them there with the help of glue. You can get these wheels from the toy shops. Also, you can remove the wheels from some old toy and use them over here. If the

slot of the wheel is wider than the axle, you can roll some tape or paper on the axle and make it thicker and then apply glue so that wheels get fixed over the axle firmly. You need to search for other pair of wheels if the slot in the wheels of axle is narrow and can't accommodate the axle of your motor. Here is how it would look like after putting the wheels in place.

The diameter of the wheels should be such that there is some clearance of the body from ground. So make sure that the wheels are big enough so that we have at least ground clearance of 1 cm.

If you want, you can have a third wheel (pivot wheel) at the back. It would not matter much even if you don't have that. The body would just drag at that point and because our material is cardboard, the friction offered would not be too much. 

