

10 Assembly

After you have made the circuit, built the body and programmed the PIC; you need to assemble everything to see if it works.



Provide voltage of 12V by using 8 X 1.5 V cells in series or a 12 V battery itself. Next you need to place the batteries in the body of the robot. Try placing it at the centre of the robot.

The sensors are mounted at front of the robot such that they are just outside the edges of black line on both sides. You can use either glue or tape

