


can use some media applications to add a song to this list.

- **Phone Vibrate:** Opens a dialog where you can set the phone to vibrate whenever you receive an incoming call, only when the phone is in Silent mode, or never.
- **Notification ringtone:** Opens a dialog where you can select the ringtone to sound when you receive a notification. Touch a ringtone to listen to it.
- **Pulse notification light:** On phones that pulse their Trackball light or other notification light when you receive a notification, check to pulse the light every few seconds when you have new notifications. Uncheck to pulse the light just once for each new notification when it arrives.
- **Audible touch tones:** Check to hear tones when you use Phone to dial a number.
- **Audible selection:** Check to play a sound when you touch buttons, icons, and other onscreen items that react to your touch.
- **Screen lock sounds:** Check to play a sound when the screen is locked or unlocked.
- **Haptic feedback:** Check to have the phone vibrate briefly when you touch soft buttons and perform other actions.



Use call settings to tweak

5.5 Display settings

Use the Display settings to configure brightness and other screen settings.

- **Brightness:** Opens a dialog for adjusting the brightness of the screen. You can check Automatic brightness to set the phone to adjust the brightness automatically, using the phone's built-in light sensor. Or uncheck that option to use the slider to set a brightness level you want at all times when using the phone. For the longest battery life between charges, use the dimmest comfortable brightness.
- **Auto-rotate screen:** Check to automatically switch the orientation of the screen as you turn the phone sideways or upright.