

- Use tactile feedback: When you have configured a screen lock, check to have the phone vibrate briefly as you touch each dot when you draw an unlock pattern or as you enter the unlock PIN or password.
- Set unlock PIN: Opens a set of screens for setting a numeric PIN you must enter to unlock your screen.
- Change unlock PIN: When a screen lock PIN is set, opens a set of screens you can use to change PIN.
- Set unlock password: Opens a set of screens for setting a password you must enter to unlock your screen.
- Change unlock password: When a screen lock password is set, opens a set of screens you can use to change password.
- Turn off screen lock: Touch to stop requiring a pattern, PIN, or password to unlock your screen. This setting is not visible unless you have configured a screen unlock pattern, PIN, or password.
- Set up SIM card lock: Opens a screen where you can configure the phone to require entering the SIM PIN to use the phone, and where you can change the SIM PIN.
- Visible passwords: Check to briefly show each character of passwords as you enter them, so that you can see what you enter.
- Select device administrators: Opens a screen with a list of the applications you have authorized to be device administrators for your phone. This is typically an email, calendar, or other enterprise application that you granted this authority to, when you added an account hosted by an enterprise service that requires the ability to implement security policies on the devices that connect to it. Touch an application in this list to disable its authority to be a device administrator; if you do, the account you added will typically lose some functionality in its applications, such as the ability to sync new email or calendar events to your phone, until you restore the application's authority as a device administrator. Applications whose device administration authority you disable in this way, but that have accounts that require them to be a device administrators, typically notify you how to restore their authority when you try to use them, unless

