


a new message and you can carry on from there depending on where you want to share the images. A handy tip here, if you are sharing an album via Gmail, will be to take care to not delete the original of an attachment before the message is completely sent (make sure it has the Sent label, not the Outbox one), or else the attachment will not be sent.

When you open an image in the Gallery you can use various options display and edit options there itself. To zoom in simply touch double tap or pinch two fingers together and spread them apart to zoo out. While zoomed in, you can swipe or drag the picture around to view others parts. You



Watching a video

will have the option to view all images in a slideshow which can be ended at any time by touching the picture on screen. At the bottom of the image will be a panel containing Share, Delete and a 'More' tab that pops open a sub-menu with various options like Set As which allows you to put up the particular image as a wallpaper or a contact picture for a friend. In both cases you will be prompted to crop the picture as per what you wish to display. Other options include Rotate Left and Right which save the picture in the new orientation and a Crop option to trim down the picture to its essentials using your fingers to adjust the margins of the cropping area. Note that you can only crop images that are on your SD card and not those synced to an app, like for instance in a Picasa web

album. After saving also the original un-cropped version will stay on the card. If you have configured Camera to save location data with your picture, you can view the location in Google Maps while looking up a picture in the Gallery.