

by its icon, we've seen my fair share of ugly icons. Unlike on your computer, you can't change icons on your phone. Next to that are the application's name and author, which might be a person or a company. You also see a notation about whether the application is installed and whether it has a cost. Below that is a rating of the application by other people who have downloaded and installed it.

8.2 Managing your applications

Whatever application you install, there are some common tips and tricks that we think you should know. First, if you like an application and think you'll use it often, you can move it to the phone's desktop so that it is more easily accessible. Just follow these steps:

- Slide the desktop to where you'd like the icon to live. Remember, your phone's desktop has three screens—the clock in the center, and a whole second and third screen to the right and left.
- Open the Application tab, and tap and hold the icon you'd like to see on your desktop.
- When the phone vibrates, the Application tab disappears and allows you to drop the icon wherever you wish.

If you want to remove an icon, tap and hold it. The Application tab turns red and changes to a trash can. Just drag the icon to the trash can, and it's gone. Second, the Menu button is your friend. If you can't figure something out, try pressing the Menu button to see what options might be there to help you out. Third, some things, such as items in a list, react to being tapped and held. So, when you are experimenting with different applications, be sure to give that method a try.

8.3 Adding applications

You can add shortcuts to the applications you've installed on your home screen. One way to do this is to drag icons to your home screen, as discussed in the preceding section. But there's another method. First, tap and hold anywhere on the home screen (that's not an application) and select Application from the pop-up menu. Every application you have on your phone is listed here.

Tap the icon you'd like to add. It shows up where you tapped and held the screen. If that's not where you want it, tap and hold the icon and drag it where you want it. If you want it on a different screen, you need to delete the icon and switch to the screen you want it on. As a review, to delete the icon, just tap and hold the icon until the phone vibrates, and drag it to the Application tab, which should now have a little picture of a trash can. When you drag over it, it turns red. When you let go, no more icon.