

- Tap Manage applications to display a list of all currently installed applications.
- Tap the most recently installed application.
- Tap the Uninstall button to uninstall your application.
- Tap OK if you want to uninstall the application or Cancel if you've changed your mind.

After you uninstall one application, reboot the phone and see if the phone performs better. If not, uninstall the next most recently installed application, reboot, and try again. If, after uninstalling a handful of applications, your phone still isn't performing well, you might need to completely reset the phone.

11.2 My Phone Crashed

You were in the middle of a call, or you were playing a game or browsing the Internet, and all of a sudden the phone just shut down without warning. What's up with that? Well, there's no way to know for sure, but the most likely explanation is that a program running on the phone did something it wasn't supposed to. Often this happens when a program tries to tell the hardware to do something it can't do.

Unfortunately, there isn't much you can do about a crash other than just power the phone back on. As soon as the phone turns back on, try to repeat the action you were taking when the phone shut down. If it shuts down again, there is probably something wrong with the application you were using. In other words, you've probably encountered a bug. Either uninstall the application, or see if an update is available for it that fixes the problem.

If the phone keeps crashing when you do something simple like making a phone call or opening the Google home page in the browser, you might need to reset the phone.

11.3 My Phone Won't Do Anything

Are you pressing buttons and nothing's happening? Have you tried to call your mobile phone from a land line and it doesn't ring? What do you do?

Well, the simple answer is that you need to reboot your phone. Follow the normal steps to reboot your phone. If those instructions don't work, you'll have to remove the phone's back cover and then remove the battery. Leave the battery out of the phone for at least 30 seconds, and then reinsert the battery and replace the back cover. Power the phone back on again; everything should return to normal. If not, you might need to reset the phone.