


How to install MeeGo on your Intel IVI system

Installing MeeGo on your Intel IVI system follows the same procedure as installing the MeeGo OS onto Your Netbook, Using a Windows App.



Adjust the partitions so you have the necessary space allocated

- ▶ Download the latest live image from <https://meego.com/downloads/releases/in-vehicle>
- ▶ Byte-copy the image to a USB drive.
- ▶ Boot the image on your Intel IVI system.

Note: that MeeGo IVI release does not include a hardware accelerated graphics driver, so all platforms will run in unaccelerated VESA mode, unless an appropriate graphics driver is added after installation.

Customise the ivihome appearance

The style of ivihome can be configured through file `/usr/share/ivihome/settings.xml`. You can redefine font style, background color, icon, text, etc. through this file. With your changes saved, run `'killall startivi'` to restart ivihome. ivihome will refresh with the new style(s) you selected.