


ferent app, press the Home button and then tap the other app's icon from the Home screen.

Switch quickly between apps

Even though only one app is visible at a time, there may be several apps running in the background. When you exit one app, it's effectively frozen until you return to it. Some apps can continue to work in the background – Mail can send and receive messages, you can listen to music, and so forth – but most apps wait until they're activated, at which point they resume where they left off. To view your most recent apps, press the Home button twice quickly. A list of recent apps appears at the bottom of the screen. Flick left on the list to view more apps, and tap the app you wish to open.



Tap on any app in the list to switch to it



Tap on the red (-) to close an app

Adjust screen brightness

Normally, the ambient-light sensor adjusts the screen brightness automatically according to its surroundings. If you'd like to dim or brighten the background light manually, you can do so in two places:

- ▶ Go to **Settings > Brightness & Wallpaper** and drag the slider left (darker) or right (brighter). To always adjust manually, turn off the Auto-Brightness switch.
- ▶ Double-press the Home button to bring up the recent apps list, swipe right, and adjust the brightness slider (located just to the left of the audio playback controls).

Multi-Touch Gestures

Until recently, most touch-screen phones, tablet computers and handhelds required that you use a stylus to do anything. Apple devices, instead, are