



Slide to Unlock the iOS device

Home screen

After you've unlocked the device, you're taken to the Home screen, which displays the software applications (or "apps") stored on the device. When iOS holds more than 20 apps, a new Home screen is created; you can see how many screens are available by looking at the dots near the bottom of the screen. Swipe left or right to switch between each screen. The shelf at the bottom of the screen holds up to six apps that remain visible on every Home screen.



Home Screen of an iPad

Press the Home button in the bezel at any time to exit an app and go to the last Home screen you were viewing. If you press the button when you're already on a Home screen, you're taken to the first screen. Or, if you're currently viewing the first screen, pressing the button displays the Spotlight search page.



Search for things in Spotlight

Launch and run apps

Tap once on an app's icon to launch it. To switch to a dif-