

- b. The `eglContextList[]` list defines the rendering context version of OpenGL® ES being used in the application. The rendering context version helps to indentify the resources required for OpenGL® ES to perform rendering operations. It is where all of the other pieces of the graphics library come together to actually display bits of information.

```

• EGLint eglContextList[] =
• {
•     EGL_CONTEXT_CLIENT_VERSION, 2,
•     EGL_NONE
• };

```

- c. In the `InitEGL()` method, the `eglBindAPI()` method globally sets the current rendering API to OpenGL® ES.

```

• eglBindAPI(EGL_OPENGL_ES_API);

```

- d. To set the EGL™ display for showing the graphic on the screen, two methods are used: `EGL_DEFAULT_DISPLAY` in the `eglGetDisplay()` method sets the EGL™ display to draw the graphics on an LCD display, while the `eglInitialize()` method is used to initialise the selected display.

```

• __eglDisplay = eglGetDisplay(EGLNativeDisplayType)
EGL_DEFAULT_DISPLAY);
•
• if(EGL_FALSE == eglInitialize(__eglDisplay, null,
null)
•     || EGL_SUCCESS != eglGetError())
• {
•     // Error handling
• }

```

- e. The `eglChooseConfig()` method enables EGL™ to match all the configuration requirements for the application using the given parameters - selected EGL™ display, required configurations, available configuration in the buffer, size of the configuration list, and the number of configurations that match the requirements.

```

• if(EGL_FALSE == eglChooseConfig(__eglDisplay, egl-
ConfigList, &__eglConfig, 1,
•     &numConfigs) || EGL_SUCCESS != eglGetError())
• {
•     // Error handling
• }

```