

angle button to view extra options, like starting a slideshow of images in the selected folder.

3. When listening to music, you can keep it playing in the background by hitting the PlayStation (home) button.
4. You can copy music, photos and videos onto your PS3 hard drive. When viewing a file, hit the triangle button and select “Copy”.

## **Xbox Live**

### **Xbox 360**

Xbox Live is an online multiplayer gaming platform provided and maintained by Microsoft. To play online on your Xbox you will have to buy an Xbox 360 Wireless Networking Adapter and an internet connection.

1. After connecting your wireless adapter, press the Guide button on your controller, go to Settings, and then select “System Settings”.
2. Go to Network Settings, select your wireless network and enter your password.

You’re now connected to Xbox Live.

## **Stream media**

Just like the PS3 you can also stream your computer data on your Xbox. All you need is the free version of the TVersity software and a Wi-Fi network.

1. The first thing you need to do is make sure that your computer and Xbox are connected to the same network.
2. After you’ve installed TVersity, run it and click on the plus symbol on the top left. Click “Browse” to select the folders you want to stream from your network hard drive.
3. If you have media in incompatible format, TVersity can translate it. Select “Transcode” when needed in the Advanced menu to convert media on the fly. TVersity will automatically start finding and sharing your files over your home network
4. Go to your Xbox and navigate to the Music, Picture, or Video Library where you will see a new category called “TVersity on [computer name]”. Select it and you will be able to see the media stored on your computer.

## **Hubs, switches, routers and access points**

In order to connect computers together on a network, we use a plethora of devices. These include hubs, switches, routers, and access points; each